


DELUXE Euro Skull Display Kit Instructions



Includes:


- 4—Screws for Assembly
- 1—1" Screw for Skull
- 4—Small Screws for Hangers
- 2—Sawtooth Hangers



1. Predrill two pilot holes in the skull.



2. Attach the hanger as shown with the 2 small screws.



3. Use **Template A** provided below to predrill two pilot holes in the Base. Attach the Base to the Brace using the 2" screws.

OPTION 1 SHOWN



4. Use **Template B** provided below to predrill two pilot holes in the Brace. (Use the diagram below to see proper placement of the template). Attach the Skull Panel to the other side of the Brace using the 2" screws.





6. Drill a small pilot hole into the location determined in step 5. Screw in the 1" screw leaving an adequate amount exposed to hang your skull.

5. Test fit the skull onto the Skull Panel. Center horizontally and vertically. Note where the skull hanger lays and make a small pencil mark on the Skull Panel. This will be the location of the 1" screw.

7. **Wall Mount Option:** To attach the hanger to the back of the Base, mark its location with a pencil and drill pilot holes. Attach using 2 small screws.

CLEANING A DEER SKULL

1. Trim away all flesh and skin. Boil the skull, removing it every 30 minutes to scrape away as much tissue as possible. Keep the antler bases out of the water. However, trim around them with a sharp knife. Use a straightened wire coat hanger to dislodge brain tissue.
2. Bleach will degrade the bone. Instead, buy 40% peroxide from a beauty supply store and pour it into a spray bottle. On a sunny day, swab and spray the skull outside, being careful to keep the liquid off the antlers or they will discolor. Repeat every 30 minutes or so until the bone is completely clean and white. This may take a few afternoons.
3. Glue loose teeth in place. Use wood stain to restore any faded antler color. Let dry.



**OPTION 1
PEDESTAL**



**OPTION 2
WALL**